


# INSTRUCTIONS FOR REPLACING A SPINNER'S ENCODER WHEEL




## WHAT YOU WILL NEED:

- A SPINNER FORK (a)**
- A NUMBER 2 PHILLIPS HEAD SCREWDRIVER (b)**
- A 7/64 inch ALLEN WRENCH (c)**

## STEP # 1:

**Power game down. Detach any harnesses connected to the spinner. Loosen wing nuts shown and remove spinner assembly from game.**



## STEP # 2:

**Using the 7/64 Allen Wrench, remove the two allen bolts that hold the ghost arrow to the pulley**

## STEP # 3

**Using the # 2 phillips head screwdriver, remove the 4 screws which hold the black spinner assembly to the white main spinner bracket. Then remove the black spinner assembly from the white main spinner bracket**

